
NOTE
Signal Path.
: FM
: AM
: CD
: DECK-A PLAY
: DECK-B PLAY
: DECK-B REC
: MIC
Abbreviations
CND: Canadian
G : German
IT : Italian
EE : East European
EA : Saudi Arabia
AR : Argentine
HK : Hong Kong
MX : Mexican
MY : Malaysia
SP : Singapore
AUS: Australian
ERASE HEAD
REC/PB HEAD (B DECK)
PLAYBACK HEAD (A DECK)
HPP101
IC401 PB EQ AMP
RV311 PB (L) LEVEL
IC401 PB EQ AMP
RV301 PB (L) LEVEL
IC402 REC/PB SWITCH
BIAS OSC
BIAS TRAP
REC BIAS
IC401 DOLBY NR/REC EQ AMP
REC LEVEL
REC EQ
BIAS SW
NORM
CROM
DOLBY NR
MUTE
LINE MUTE
IC1701 POLAR DEMODULATOR
IC1703 ANALOG SWITCH
MONO SWITCH
STEREO SWITCH
POLAR/STEREO SWITCHING
SUB CARRIER LEVEL
SUB CARRIER Q PEAK
VCO STOP
IC1 PLL
CE
DATA
CLK
B.IN
DATA IN
CLOCK
DATA OUT
IF REQ
FM LOW
FM/AM IF
ST-MUTE
STEREO
TUNER
AUX IN
J101
J701
MIC AMP
IC1102 INPUT SELECTOR
DECODER
FE2 FM FRONT-END
FE2 LW/MW FRONT-END
MW/LW SWITCHING
AEP, EE UK, CIS
CNG, G, IT, E2, AR, MX, AUS
E3, EA, HK MY, SP